



DOUBLE IBC




ASSEMBLY INSTRUCTIONS




1. Place the sump on a flat surface and position the grids as shown.







2. Position the corner profile and place the bolts onto the M8 nuts on the sump.





3. Assemble the other three corner profiles as described above.



4. Position the short panel to the sump using M8 bolts, and secure it to the corner profile with M8 bolts and nuts.



5. Assemble the other short panel and one long panel as described above.



6. Assemble the door panel in the same way.



7. Position the roof connection bolts with the panels.



portablespace®

cabin & container hire | sales | conversions | modular

Portable Space Ltd,
Modular House, Bacton Business Park,
Stowmarket, Suffolk, IP14 4LE

T: +44(0) 01449 782123
info@portablespace.co.uk
www.portablespace.co.uk